

Valley Road Classroom Equipment



DVD Operations *(Standard Classrooms)*

Step 1: Make sure the [projector](#) is on and ready for projection. Make sure the [projection screen](#) is down.



Extron Panel

Step 2: Press the button above "DVD" on the Extron Panel, located on the top of the podium.

Step 3: Press the "Standby/On" button to on, located on the DVD equipment.

Step 4: Press the "Open/Close" button and insert a DVD disk.

Step 5: Please use the controls located on the DVD or the remote control which is housed in the podium.

Step 6: Adjust the volume by using the "Volume" control knob located on the Extron Panel.



Volume Control Knob

Step 7: When finished using the DVD, please turn the DVD power off by pressing the "Standby/On" button to standby.