

Valley Road Classroom Equipment



Projector Operations (Standard Classrooms)

Step 1: Locate the Extron Panel on top of the podium. Press and hold the "Display Power" button until the light starts to blink. The green light will blink as the projector powers up, this may take about 30 to 45 seconds.



Step 2: When the green light stays lit, the projector is ready for projection. You may operate the Document Camera, the VCR, the DVD, or the computer.

Step 3: To turn the projector off, press and hold the "Display Power" button until the light starts to blink. The light will blink as the projector powers down. You will not need to do anyting else.

Please remember to turn off the projector after you are finished using it.

This is extremely important.