

Valley Road Classroom Equipment



**Projection Screen Operations
(Tiered Classrooms)**



Crestron Display

Step 1: Locate the Crestron Display on top of the podium. It is an LCD touch screen monitor.

Step 2: Locate the screen controls on the right and left side of the Creston Display. Press the down arrows.



Screen Controls

Step 3: Please be sure to raise the screens when finished using them by pressing the up arrows on the Crestron Display.

-OR-

Step 1: To lower and raise the screens, use the control located next to the light switches on the wall.

Step 2: Please be sure to raise the screen when finished using it.

Screen Controls

