Valley Road Classroom Equipment


Projector Operations
(Tiered Classrooms)

Crestron Display

Step 1: Locate the Crestron Display on top of the podium. It is an LCD touch screen monitor.

Step 2: If the screen is blank, touch the screen and a welcome sign will appear.

Crestron Welcome Screen

Step 3: Touch the screen again and the system will turn on.

Step 4: Turn on each projector located in the lower left and right side of the screen. Just touch the word "On".


Projector On/Off

Step 5: When finished using the projectors, turn them off by touching the "Off" located in the lower right and left side of the screen. **This is extremely important!**

Step 6: Touch the red icon in the upper left-hand corner of the Crestron Display to turn off the entire system. It will take 3 minutes to shut down the system.

System Off

NOTE: If you want the projection to display through both screens, touch the box located in the lower-middle of the screen. If you want to display on only the right or the left screen, than just touch the display at the bottom right or left screen.

Both Screens

Please remember to turn off the projector after you are finished using it.

This is extremely important.